


## **DIMENSIONS (mm)**

Part No.	Size (mm)			
	Α	В	С	D
JCB 201209 (0805)	2.0 ± 0.2	1.2 ± 0.2	0.9 ± 0.2	$0.5 \pm 0.3$

No.	Part No.	Impedance	Test Frequency	RDC (Ω)	IDC (mA)
		(Ω)	(MHz)	(MAX)	(MAX)
1	JCB 201209-110	11 ± 25%	100	0.15	600
2	JCB 201209-320	32 ± 25%	100	0.15	400
3	JCB 201209-800	80 ± 25%	100	0.15	300
4	JCB 201209-121	120 ± 25%	100	0.25	300
5	JCB 201209-151	150 ± 25%	100	0.25	300
6	JCB 201209-221	220 ± 25%	100	0.30	200
7	JCB 201209-301	300 ± 25%	100	0.30	200
8	JCB 201209-501	500 ± 25%	100	0.30	200
9	JCB 201209-601	600 ± 25%	100	0.35	200
10	JCB 201209-102	1000 ± 25%	100	0.45	200


## **RECOMMENDED PATTERN (mm)**

Туре	Α	В	С
JCB 201209	0.80	1.00	1.00



PACKAGE		
Туре	JCB 201209	
Q'TY/Reel	4000	





## Application Notice

## • STORAGE

- 1. The solderability of the external electrode may be deteriorated if packages are stored where they are exposed to high humidity. Packages must be stored at  $40^{\circ}$ C or less and 70% RH or less.
- 2. The solderability of the external electrode may be deteriorated if packages are stored where they are exposed to dust or harmful gas (hydrogen chloride, sulfurous acid gas or hydrogen sulfide).
- 3. Packaging material may be deformed if packages are stored where they are exposed to heat or direct sun-light.
- 4. Minimum packages, such as polyvinyl heat-seal packages shall not be opened until just before they are used. If opened, use the reels as soon as possible.
- 5. Recommended products should be used within 6 months form the time of delivery. For those parts which passed more than 6 months shall be checked solderability before it is used.
- Transportation

Care should be taken when transporting or handling product to avoid excessive vibration or mechanical shock.